

GPRS MODE INSTRUCTIONS

The Mongoose PT301 and VT401 GPS trackers can alternatively communicate via GPRS to a computer rather than GSM text messages.

At this time, Mongoose does not offer any software to enable GPRS reception on your computer and advise you to contact an IT provider such as Sniper Systems (64 9 5234202).

To configure either GPS tracker model, follow these text commands;

7100000

Sets GPRS mode

*CELLNUMBER*0000*1**

Set telephone number for user 1

#803#0000#APNNAME##

Set GPRS apn

#804#0000#IPADDRESSOFTCLISTENER#PORTNUMBER##

Set GPRS server IP and port

#806#0000##

Send coordinates now

#805#0000#READEVERYXSEC#UPLOADTHISMANYREADINGSEACHTIME##

Send coordinates periodically

RESPONSE data will be in this format

003cedfb	cell tower id
GPRMC	static
022227.505	time (gmt)
V	position state
3646.3230	latitude
S	latitude direction
17444.0495	longitude
E	longitude direction
xxx	speed
xxx	direction
170609	date (ddmmyy)
	"informationstate"
	"informationstate"
N	"informationstate"
*6A	"informationstate"